


## **LED Flasher**



Connect YELLOW wires of all heads together for synchronization (all heads must be set at the same pattern)

## For Simultaneous or Alternating Flash:

- Apply +VDC to RED and YELLOW wires simultaneously to enter Grouping mode; lighthead will display short (single or double) flashes:
  - Single flash = Group1
- Double flash = Group2
- Remove YELLOW wire from +VDC and momentarily apply to +VDC to change Groups:
  - · Heads in the same Group flash together.
  - · Group1 Heads alternate with Group2 Heads.

## For Flash Patterns:

Momentarily apply +VDC to YELLOW wire:

- · once for next pattern
- quickly three times for pattern 0

NOTE: This unit may not be factory set at FP# 0.

FP#	Flash Patterns		
0	Random	10	Double (all)
1	Single (split)	11	Quad (all)
2	Double (split)	12	Quint (all)
3	Quad (split)	13	Mega (all)
4	Quint (split)	14	Ultra (all)
5	Mega (split)	15	Single-Quad (all)
6	Ultra (split)	16	Single H/L (all)
7	Single-Quad (split)	17	Steady 2 (CA)
8	Single H/L (split)	18	Steady 4 (all)
9	Single (all)		

<sup>\*</sup>SPLIT=Left alternate Right

\*ALL=Simultaneous